

At BoneView we are thoroughbred hunters at heart. Born deep in the bluff country of Wisconsin, we develop innovative products to enhance the hunting experience and increase a hunter's odds of success. BoneView allows hunters to check trail camera SD cards on their smartphone or tablet, providing convenient and instant access to trail camera data when they need it most.

"With BoneView you can take your scouting and stand selection to the next level!"

HOW IT WORKS

Always insert SD or microSD card into reader slot BEFORE connecting to phone or tablet and ensure SD card slide tab is not "locked".

Connect BoneView to your device at the charge port.

A notification will appear on the screen directing you to download the free app called "BoneView" available in the app store, or visit: [**boneview.com/apps**](http://boneview.com/apps)

With BoneView app open, tap on "SD Card" circle in the middle of the home screen to locate trail camera files.

While in "SD Card" folder, navigate to the folder with photos - often stored in a "DCIM" folder and then in a folder specific to your camera.

To save tap "Edit" at top right and then select one or several files, or use the "Select All" command.

Tap "Copy, Cut, or Delete" on the bottom menu to copy, move, or delete selected photos or videos.

After "Copy" or "Cut" command is used, choose "App Storage" to save files in the App's folder, or choose "Album" to save directly in your phone's Photo Gallery. Tap on "Paste" at top right of screen to complete the file transfer.

Go back to home screen and choose "App Storage" to see the saved photos if stored there, or "Album" if you chose to save in the standard photo gallery / camera roll location.

Always disconnect reader from phone before inserting new SD cards to view, close app, then reconnect with new SD card already inserted to start over. Never disconnect while files are being read, deleted, or transferred to avoid SD card file damage.

If app doesn't respond, then close app entirely or restart phone if necessary and start over with a fresh start. Also check the app store and keep app updated for best performance.

USER TIPS & TROUBLESHOOTING

How to Play Video Files

• Some unique video files may not be recognized. Improve video file recognition by using the free VLC for Mobile app; Go to Settings and choose "Apply 3rd Party Player: VLC" to download and use this player.


Deleting / Formatting All Files Quickly

• When trying to delete all files at once, consider going to "Settings", and using "Format SD Card" option. This will be quicker than Select-All / Delete when greater than 100 files. Doing this routinely also improves memory card performance.

Trouble Reading Memory Card

• Be sure SD card is 4-GB or larger or formatted to FAT/FAT32. Ensure card is fully inserted into BoneView before connecting to phone or tablet. Try a different card or a clean formatted card that has standard photos on it.

Quick Save / Share Feature in Full-Screen Mode

• Once a photo is in full-screen view, swipe left/right to continue scanning through, and tap the "Share" icon  to see options to share or save.

WARRANTY

Register your purchase below to confirm purchase from authorized dealer and secure Lifetime Product Support and Coverage. Warranty does not apply to units which have been damaged or abused intentionally or unintentionally. Registration of order information must be confirmed for any warranty service or product replacements.

REGISTER NOW HERE: [www.boneview.com/warranty**](http://www.boneview.com/warranty)**